

Make "Opening" More Fun

How can we make opening something more fun? Under this concept, we developed a card case.


We designed the case so that opening it would be hard to figure out; consequently, the case is quite a unique item that is definitely not for everybody. The feeling of surprise upon opening the case and the comforting click of the lid are part of the product's appeal. Available in a variety of colors, this product can be customized and made your own.

Perfect for storing mints or other tablet-shaped items.

How to use




Hold the case with both hands as shown in Picture 2. Push and slide the part of



If you push this part of the case, the lid to the upper part of the case will open to the left.

Made in JAPAN



Open the lid wide and remove the cards inside.

*When closing the lid, be sure to press firmly until you hear a click.

PUSH PLUS+

Card Case

Material: Polypropylene
Upper temperature limit: 100°C
Size: 74 (w) × 13.5 (d) × 98 (h) mm
Max. size of card: 60 mm (w) × 90 mm (l)
(Business cards, shop loyalty cards, electronic money cards, etc.)
Capacity: About 30 business cards

[Precautions]

- · Do not place near fire.
- $\boldsymbol{\cdot}$ Do not apply excessive force to the case. Doing so may cause the case to break.
- When storing the case, avoid exposure to direct sunlight and store in a cool place.
- If a problem is detected with the case, discontinue use.
- When storing items that absorb moisture or change properties easily, try to eat or use the items quickly.
- Do not store items in the case over an extended period of time.
- We reserve the right to make improvements by changing the shape or color of the product without prior notice.

HIRO-PLUS

Manufacturer/Distributor: HIRO-PLUS Co., Ltd. 5th Floor, Hirohama Building, 2-28-11 Ishihara, Sumida-ku, Tokyo 130-0011 Japan

Contact: info@hiro-plus.com

http://www.hiro-plus.com/pushplus

